

USB Exported Control API	1
---------------------------------	----------

USB Exported Control API

USB Exported

API

- [BS2_AllocateUsbContext](#): USB Context
- [BS2_ReleaseUsbContext](#): USB Context
- [BS2_GetUserDatabaseInfoFromDir](#): USB Data (,) 가
- [BS2_GetUserListFromDir](#): USB Data ID 가
- [BS2_GetUserInfosFromDir](#): USB Data ID 가
- [BS2_GetUserDatasFromDir](#): USB Data UserMask ID 가
- [BS2_GetUserInfosExFromDir](#): USB Data ID 가 . (Job, phrase)
- [BS2_GetUserDatasExFromDir](#): USB Data UserMask ID 가 . (Job, phrase)
- [BS2_GetUserSmallInfosFromDir](#): [+ 2.6.3] USB Data ID 가
- [BS2_GetUserSmallDdatasFromDir](#): [+ 2.6.3] USB Data UserMask ID 가
- [BS2_GetUserSmallInfosExFromDir](#): [+ 2.6.3] USB Data ID 가 . (Job, phrase)
- [BS2_GetUserSmallDdatasExFromDir](#): [+ 2.6.3] USB Data UserMask ID 가 . (Job, phrase)
- [BS2_GetLogFromDir](#): USB Data 가
- [BS2_GetLogBlobFromDir](#): USB Data EventMask 가
- [BS2_GetFilteredLogFromDir](#): USB Data 가
- [BS2_GetLogSmallBlobFromDir](#): [+ 2.6.4] EventMask 가 , USB Data

From:

<https://kb.supremainc.com/kbtest/> - **BioStar 2 Device SDK**

Permanent link:

https://kb.supremainc.com/kbtest/doku.php?id=ko:use_exported_control_api&rev=1581939989

Last update: **2020/02/17 20:46**