

Table of Contents

API & References	1
-----------------------------------	---

API & References

You can check the details of the API.

- [Return Code](#)

This page provides the information of the return codes.

- [SDK API](#)

This API provides functionality for initializing the SDK and managing the memory.

- [Communication API](#)

This API allows to connect with the device.

- [Device API](#)

This API allows to control the device.

- [Log Management API](#)

This API allows to get/write/delete the log data.

- [Access Control API](#)

API for access control, which can manage access authority by individual, group, time schedules.

- [Door Control API](#)

API that configures whether the device is set as entrance/exit of the door, how the device will control the door, and the APB settings.

- [Wiegand API](#)

API that composes the Wiegand card readers and configures the Wiegand input/output.

- [Server API](#)

API that can enable server matching or controls the device from the BioStar application.

- [SSL API](#)

API that configures the SSL communication

- [User Management API](#)

This API allows to get/enroll/delete the user information.

- [Configuration API](#)

This API allows to get/set the configuration information.

- [Smartcard API](#)

This API allows to scan the smart card.

- [QR code API](#)

API that provides functions to read and write QR code data.

- [Fingerprint API](#)

This API allows to scan/verify the fingerprint template.

- [Face API](#)

This API allows to scan/verify the face template.

- [Blacklist API](#)

API that adds a card to the blacklist when a card is lost or to limit access.

- [Slave Control API](#)

API that connects the master and slave device by using the RS-485 network.

- [Zone Control API](#)

API that configures the zone, which can control the entry device and door's operations.

- [Useful Articles](#)

Useful articles that explain detailed information.

- [Lift Control API](#)

API that configures the OM-120, which can control lifts.

- [USB Exported Control API](#)

API that configures USB Exported.

From:

<https://kb.supremainc.com/kbtest/> - **BioStar 2 Device SDK**

Permanent link:

https://kb.supremainc.com/kbtest/doku.php?id=en:api_references

Last update: **2021/09/07 11:21**