

Table of Contents

BS2_RemoveAllInterlockZone	1
Declaration	1
Parameter	1
Return Value	1
See Also	1

[Zone Control API](#) > [BS2_RemoveAllInterlockZone](#)

BS2_RemoveAllInterlockZone

[+ V2.6.0] Removes all Interlock zones.

Declaration

```
#include "BS_API.h"

int BS2_RemoveAllInterlockZone(void* context, uint32_t deviceId);
```

Parameter

- [In] *context* : Context
- [In] *deviceId* : Device ID

Return Value

If successfully done, BS_SDK_SUCCESS will be returned.
If there is an error, the corresponding error code will be returned.

See Also

[BS2_GetInterlockZone](#)
[BS2_GetInterlockZoneStatus](#)
[BS2_GetAllInterlockZoneStatus](#)
[BS2_SetInterlockZone](#)
[BS2_SetInterlockZoneAlarm](#)
[BS2_RemoveInterlockZone](#)

From:
<http://kb.supremainc.com/bs2sdk/> - **BioStar 2 Device SDK**

Permanent link:
http://kb.supremainc.com/bs2sdk/doku.php?id=en:bs2_removeallinterlockzone

Last update: **2018/03/15 14:23**