

# Table of Contents

BioStar 1 .....	1
General .....	1
Connection .....	1
Database .....	1
System Integration .....	2
Operation .....	2

[FAQ, BioStar 1](#)

# BioStar 1

Frequently asked questions about BioStar 1.

## General

- [BioStar V1.8 Server Matching](#)
  - [Differences between BioStar Videophone and BioStar Videophone Beta](#)
  - [Automatic time synchronization](#)
  - [MSB and LSB in Card ID Format](#)
  - [Installing BioStar on Windows 10](#)
  - [How to install USB driver on Windows 8 64bit](#)
  - [Error messages related to BioStar Software License](#)
  - [MTU and Suprema devices](#)
  - [How to enroll a fingerprint](#)
  - [How to resolve False Rejection Issue](#)
  - [How to Upgrade BioStar 1](#)
- 

## Connection

- [Understanding Wiegand](#)
  - [How to connect Secure IO to BioStation T2](#)
  - [How to connect two devices to one door without using RS485](#)
  - [What network port BioStar server & device use](#)
  - [Connection Mode in BioStar 1](#)
- 

## Database

- [SQL Server failure under Windows 7 64 bits](#)
- [How to distinguish T&A event type in the BioStar database](#)
- [How to get leave data from the BioStar database](#)
- [Oracle query - Time and date conversion](#)
- [How to configure the Oracle settings to run BioStar](#)
- [How to create a SQL server authentication login ID](#)
- [How to update an existing MS SQL database using DBSetup](#)
- [How to restore a database backup in MSSQL Server](#)
- [How to make a backup of MSSQL database](#)
- [Database Restoration Error - The media set has 2 media families](#)
- [How to solve the Cannot Generate SSPI Context error](#)
- [How to Resolve a Database Compatibility Issue](#)

## System Integration

- [BioStar Database integration guide](#)
  - [How to connect AXIS NVR with BioStar](#)
  - [How to use AXIS NVR in BioStar](#)
  - [How to assign an unsigned integer value in Visual Basic 6](#)
- 

## Operation

- [When you forgot the admin password to log in to BioStar Client](#)
- [How to create an Access Group](#)
- [How to issue Bypass cards](#)
- [How to use Lift I/O](#)
- [How to open and close doors in BioStar 1](#)
- [How to troubleshoot an error message \[Fail to save data to server\]](#)
- [How to secure the device and user information](#)
- [How to configure the duress detection feature](#)
- [How to configure the email notification settings](#)
- [How to unlock a device using Challenge Code](#)
- [How to configure the alarm settings](#)
- [How to add custom alarm sounds](#)
- [How to get log records from slave devices](#)
- [How to configure the WLAN settings](#)
- [How to delete cards registered to a user](#)
- [How to block users based on the template card number](#)
- [How to upgrade firmware of your Suprema device](#)
- [How to manage user data in your device](#)
- [How to assign different administrative privileges to users](#)
- [How to register Command card](#)
- [How to set up an Anti-passback zone](#)
- [How to set up a fire alarm zone](#)
- [How to issue a card](#)
- [How to delete a card](#)
- [How to export device logs](#)
- [How to set up an alarm zone](#)
- [How to create an administrator on BioLite Solo using an one-time password](#)
- [How to use an external Wiegand reader](#)
- [How to configure Mifare Site Key](#)
- [How to change language in devices](#)
- [How to configure MIFARE card memory layout](#)
- [How to troubleshoot if logs aren't uploading automatically in server mode](#)
- [Troubleshooting T&A Reports with Wrong Results](#)
- [Troubleshooting T&A Report Absence Issue](#)

From:

<https://kb.supremainc.com/knowledge/> -

Permanent link:

[https://kb.supremainc.com/knowledge/doku.php?id=en:faq\\_biostar1x](https://kb.supremainc.com/knowledge/doku.php?id=en:faq_biostar1x)

Last update: **2017/01/17 11:29**