2024/09/09 21:39 / How to Configure Alerts

## **Table of Contents**

2024/09/09 21:39 1/5 How to Configure Alerts


System Configuration, BioStar 2, Alert, custom alert, alert sound

## **How to Configure Alerts**

The alert feature is used to notify the BioStar administrator when specific device/door/zone/authentication event occurs.

The Alert history can be accessed through BioStar 2 → Monitoring → Alert History

Or by clicking on the alert count located on the bottom right corner of the BioStar web client.



BioStar 2 alert messages get displayed for administrative level users in three ways.

1. BioStar 2 → Monitoring → Real-time Log

The specified event will be colored red on the real-time log.

Note: The color of the alert message cannot be customized)



2. A popup message on the screen of BioStar 2

2024/09/09 21:39 2/5 How to Configure Alerts

An alert popup message appears, and then the administrator can either click acknowledge or ignore.

[Alert Message can be customized :follow "Configuring the Popup Message" at the bottom of this article]




3. An alert sound Particular alert sound will be played at the occurrence of the event.

The sound feature is only available BioStar 2 version 2.3 or above


==== Configuring the Real-time Log Event Message ====

1. Click on **Setting** → **ALERT**.




2. Click on the checkbox for the events you want alerts for and click **Apply**.

2024/09/09 21:39 3/5 How to Configure Alerts




3. Now the checked event will appear red on the **Real-time log** when the event occurs.



- ==== Configuring the Popup Message ====
- 1. Click **Settings** → **ALERT** to access the **Alert** menu.
- 2. Click on the document icon on the right side of a particular alert message you want to customize



3. Enter your message and click **Apply** to save the settings.



- ==== Configuring the Sound Alert ====
- 1. Click **Settings** → **PREFERENCE**.
- 2. Click + Add button in the Sound tab.

2024/09/09 21:39 4/5 How to Configure Alerts




3. Browse your PC and add a sound file.



- 4. Click **Add** and then click **Apply**.
- 5. Click **Settings** → **ALERT**.
- 6. Click on the document icon of a desired event.
- 7. On the Sound Name drop box select the sound you uploaded on the preference menu.
- 8. Select your play option.

Play Options **Once** will run the sound file once

Play Options **Loop until acknowledge** will run the sound until user clicks acknowledge on the popup menu that appears when the event occurs.



2024/09/09 21:39 5/5 How to Configure Alerts

From:

https://kb.supremainc.com/knowledge/ -

Permanent link:

https://kb.supremainc.com/knowledge/doku.php?id=en:how\_to\_configure\_alerts

Last update: 2022/12/28 12:59

<sup>-</sup> https://kb.supremainc.com/knowledge/