

Table of Contents


How to configure the alarm settings 1

BioStar 1, Alarm Setting

How to configure the alarm settings


You can configure the alarm settings to specify an alarm sound to play and an email address for receiving alarm notifications, and decide whether to activate an alerting popup.

1. Go to **Option > Event > Alarm Setting**:




2. Step one brings up the **Alarm Setting** dialog. Set the **Select Priority Level** drop-down list to the priority level you want. Check the options you want to choose under the **Action** section and click **Add**.

- **Program Sound:** If set, you can choose what sound to play and set the duration when an alarm sets off.
- **Send Email:** If set, an email containing the information on an alarm will be sent to an email address registered here.
- **Acknowledge:** If set, a popup window indicating that an alarm log record has been received from a device will show up on a PC where a BioStar client is running.



3. On the **All Event** dialog, check all the events you want to add and click **OK**.



4. Click **Save** to finish the settings.

From:

<https://kb.supremainc.com/knowledge/> -

Permanent link:

https://kb.supremainc.com/knowledge/doku.php?id=en:1xfaq_how_to_configure_the_alarm_settings

Last update: **2019/12/31 11:27**