

Table of Contents

How to open and close doors in BioStar 1	1
--	---


BioStar 1

How to open and close doors in BioStar 1

BioStar allows administrators or operators to control doors, alarms, and devices remotely. You can open or close doors via a computer connected to the BioStar Client. You can also release (cancel) alarms remotely and lock or unlock devices.


To open or close doors:

On the **Monitoring** page, click the door name then click **Open Door** or **Close Door**.




To open door only for the door open period set in the doors:

On the **Monitoring** page, click the door name then click **Exit Button**.



To release an alarm:
Click the door name then click **Release Alarm**.



From:

<https://kb.supremainc.com/knowledge/> -

Permanent link:

https://kb.supremainc.com/knowledge/doku.php?id=en:1xfaq_how_to_open_and_close_doors_in_biostar

Last update: **2015/10/07 13:20**