

Table of Contents

Entrance Limit Zone	1
---------------------------	---

Entrance Limit Zone

A zone that restricts access at specific times.

This zone can be configured in such a way as to restrict the authentication or the authentication count.

From:

<https://kb.supremainc.com/knowledge/> -

Permanent link:

https://kb.supremainc.com/knowledge/doku.php?id=en:entrance_limit_zone

Last update: **2019/01/02 15:22**