

目次


アンチパスバック(APB)ゾーンの設定	1
動画デモ	4

システム構成, BioStar 2, アンチパスバック

アンチパスバック(APB)ゾーンの設定


始める前に、Standard

以上ライセンスの活性化状態を確認してください。ライセンスが活性化すると、下記のように左側のメニューボタンでゾーンメニューを確認することができます。



1. ゾーン追加(ADD


ZONE)をクリックした後、アンチパスバック(Anti-passback)を選択し確認をクリックしてください。



2. アンチパスバックゾーン名を入力し、希望に応じて構成してください。APB規則に違反するユーザーを遮断するには、アンチパスバックの種類をハードAPBに設定し、初期化時間が予想時間より短くならないようにします。次に、入室デバイスおよび退室デバイスを設定してください。



3. デバイスリレーを使って、アラームサウンドを出すために必要な場合には動作を設定します。



4. APB規則に関係なく、APBゾーンにある出入口を通過できるアンチパスバックバイパスグループを設定します。管理者がサイトで便利に修正できるよう、このグループの使用をお勧めします。



5. 設定終了後にAPBをテストし、モニタリングで警報およびゾーン状態を確認します。

The screenshot shows a web interface for 'Zone Status'. At the top left, there is a location pin icon and the title 'Zone Status'. Below the title is a 'Save Filter' button. A table below shows the status of zones. The table has columns for 'Type', 'Zone Name', 'Active/Inactive', and 'Status'. One row is visible with 'Anti-passback' as the type, 'Test' as the zone name, 'Active' as the status, and 'Normal' as the overall status. A modal window titled 'ACCESS_DENIED_APB' is open in the center. It contains the following information:

- User: Administrator
- Device: BioStation 2 100000007 (192.168.16.205)
- Alarm: Violation of anti-passback
- Date: 2015/09/16 16:46:18

Below the information is a 'Comments' text area and two buttons: 'Acknowledge' and 'Ignore'.

動画デモ

[apb.mp4](#)

From:
<http://kb.supremainc.com/knowledge/> -

Permanent link:
http://kb.supremainc.com/knowledge/doku.php?id=ja:how_to_configure_apb_zone&rev=1566540722

Last update: **2019/08/23 15:12**