

- SDK API** ..... 1
- initialize** ..... 1
- ..... 1
- run** ..... 1
- ..... 1
- getVersion** ..... 2
- ..... 2
- ..... 2
- setCardType** ..... 2
- ..... 2
- ..... 2
- connectFtpServer** ..... 3
- ..... 3
- ..... 3
- disconnectFtpServer** ..... 3
- ..... 3
- getFirmwareFileList** ..... 4
- ..... 4
- ..... 4
- upgradeFirmware** ..... 4
- ..... 4
- ..... 4

# SDK API

## initialize

SDK

```
void initialize(Context context, DeviceListener listener)
```

- context : android application context.
- listener : 가

DeviceListener

가 SDK가 가

## run

SDK

```
int run()
```

SUCCESS 가

SDK 가

## getVersion

SDK / Firmware 가 .

```
int getVersion(Version version)
```

- version : SDK / Firmware

Version

SUCCESS 가 .

## setCardType

RF .

```
int setCardType(int cardType)
```

- cardType : RF

1	HIGH_FREQUENCY
2	HIGH_FREQUENCY_ICLASS
3	LOW_FREQUENCY
4	LOW_FREQUENCY_PROX

SUCCESS 가 .

# connectFtpServer

FTP

```
int connectFtpServer(FirmwareOption option)
```

- option:

FirmwareOption

SUCCESS 가

```

API FTP
FTP
\\
<uses-permission android:name="android.permission.INTERNET"/>
<uses-permission
android:name="android.permission.WRITE_EXTERNAL_STORAGE" />

```

# disconnectFtpServer

FTP

```
int disconnectFtpServer()
```

SUCCESS 가

```

API FTP
FTP

```

## getFirmwareFileList

FTP

```
int getFirmwareFileList(ArrayList<String> fileList)
```

- fileList:

SUCCESS

가

API FTP

FTP

## upgradeFirmware

```
int upgradeFirmware(FirmwareOption option)
```

- option:

FirmwareOption

SUCCESS

가

API FTP

FTP

From:

<https://kb.supremainc.com/svpsdk/> - **SVP Android SDK**

Permanent link:

[https://kb.supremainc.com/svpsdk/doku.php?id=ko:sdk\\_api&rev=1543822755](https://kb.supremainc.com/svpsdk/doku.php?id=ko:sdk_api&rev=1543822755)

Last update: **2018/12/03 16:39**