

- SDK API** 1
- initialize** 1
- 1
- run** 1
- 1
- getVersions** 2
- 2
- 2
- setCardType** 2
- 2
- 2
- connectFtpServer** 3
- 3
- 3
- disconnectFtpServer** 3
- 3
- getFtpFileList** 4
- 4
- 4
- getUsbFileList** 4
- 4
- 5
- upgradeFirmware** 5
- 5
- 5
- rebootDevice** 5
- 6

SDK API

initialize

SDK

```
void initialize(Context context, DeviceListener listener)
```

- context :
- listener : 가

DeviceListener

가 SDK가 가

run

SDK

```
int run()
```

SUCCESS 가

SDK 가

getVersions

SDK / Firmware 가 .

```
int getVersions(Versions versions)
```

- versions : SDK / Firmware

Versions

SUCCESS 가 .

setCardType

RF .

```
int setCardType(int cardType)
```

- cardType : RF

1	HIGH_FREQUENCY
2	HIGH_FREQUENCY_ICLASS
3	LOW_FREQUENCY
4	LOW_FREQUENCY_PROX

SUCCESS 가 .

connectFtpServer

FTP

```
int connectFtpServer(FirmwareOption option)
```

- option:

FirmwareOption

SUCCESS

가

API FTP

FTP

API

```
<uses-permission android:name="android.permission.INTERNET"/>
```

disconnectFtpServer

FTP

```
int disconnectFtpServer()
```

SUCCESS

가

API FTP

FTP

API

```
<uses-permission android:name="android.permission.INTERNET"/>
```

getFtpFileList

FTP

```
int getFtpFileList(ArrayList<String> fileList)
```

- fileList:

SUCCESS

가

API FTP

FTP

API

```
<uses-permission android:name="android.permission.INTERNET"/>
```

getUsbFileList

USB

```
int getUsbFileList(ArrayList<String> fileList)
```

- fileList:

SUCCESS

가

upgradeFirmware

```
int upgradeFirmware(FirmwareOption option)
```

- option:

FirmwareOption

SUCCESS

가

API FTP

FTP

API

```
<uses-permission android:name="android.permission.INTERNET"/>  
<uses-permission  
android:name="android.permission.WRITE_EXTERNAL_STORAGE" />
```

rebootDevice

```
int rebootDevice()
```

SUCCESS

가

.



From:
<https://kb.supremainc.com/svpsdk/> - **SVP Android SDK**

Permanent link:
https://kb.supremainc.com/svpsdk/doku.php?id=ko:sdk_api&rev=1545637341

Last update: **2018/12/24 16:42**