

Table of Contents

BS2_GetLogFromDir	1
Declaration	1
Parameter	1
Return Value	1
See Also	1

BS2_GetLogFromDir

Gets the maximum amount of logs starting from the given log record ID from storage path in device.

Declaration

```
#include "BS_API.h"

int BS2_GetLogFromDir(void* context, const char* szDir, BS2_EVENT_ID
eventId, uint32_t amount, BS2Event** logsObj, uint32_t* numLog);
```

[See BS2Event Structure](#)

Parameter

- [In] *context* : Context
- [In] *szDir* : Storage path in device
- [In] *eventId* : Log record ID. When the value is 0, gets the logs from the beginning.
- [In] *amount* : Maximum number of logs. When the value is 0, gets the logs starting from the event ID.
- [Out] *logsObj* : Pointer to store the log record's address.
- [Out] *numLog* : Number of log record.

NOTE

The *logsObj* variable needs to return the memory to the system by the [BS2_ReleaseObject](#) function after being used.

Return Value

If successfully done, `BS_SDK_SUCCESS` will be returned.
If there is an error, the corresponding error code will be returned.

See Also

[BS2_AllocateUsbContext](#)

BS2_ReleaseUsbContext
BS2_GetUserDatabaseInfoFromDir
BS2_GetUserListFromDir
BS2_GetUserInfosFromDir
BS2_GetUserDatasFromDir
BS2_GetUserInfosExFromDir
BS2_GetUserDatasExFromDir
BS2_GetLogBlobFromDir
BS2_GetFilteredLogFromDir

From:

<https://kb.supremainc.com/kbtest/> - **BioStar 2 Device SDK**

Permanent link:

https://kb.supremainc.com/kbtest/doku.php?id=en:bs2_getlogfromdir

Last update: **2022/04/21 11:17**