

Table of Contents

BS2_GetAntiPassbackZoneStatus	1
Declaration	1
Parameter	1
Return Value	1
See Also	1

BS2_GetAntiPassbackZoneStatus

Retrieves the status of selected Anti Passback zones.

Declaration

```
#include "BS_API.h"

int BS2_GetAntiPassbackZoneStatus(void* context, BS2_DEVICE_ID deviceId,
BS2_ZONE_ID* zoneIds, uint32_t zoneIdCount, BS2ZoneStatus** zoneStatusObj,
uint32_t* numZoneStatus);
```

[See BS2ZoneStatus Structure](#)

Parameter

- [In] *context* : Context
- [In] *deviceId* : Device ID
- [In] *zoneIds* : List of Anti Passback zone IDs to retrieve
- [In] *zoneIdCount* : Size of the Anti Passback zone ID list
- [Out] *zoneStatusObj* : Zone status list pointer
- [Out] *numZoneStatus* : Number of zone status records

NOTE

The *zoneStatusObj* variable needs to return the memory to the system by the [BS2_ReleaseObject](#) function after being used.

Return Value

If successfully done, `BS_SDK_SUCCESS` will be returned.
If there is an error, the corresponding error code will be returned.

See Also

[BS2_GetAntiPassbackZone](#)

[BS2_GetAllAntiPassbackZone](#)
[BS2_GetAllAntiPassbackZoneStatus](#)
[BS2_SetAntiPassbackZone](#)
[BS2_SetAntiPassbackZoneAlarm](#)
[BS2_RemoveAntiPassbackZone](#)
[BS2_RemoveAllAntiPassbackZone](#)
[BS2_ClearAntiPassbackZoneStatus](#)
[BS2_ClearAllAntiPassbackZoneStatus](#)

From:

<http://kb.supremainc.com/bs2sdk/> - **BioStar 2 Device SDK**

Permanent link:

http://kb.supremainc.com/bs2sdk/doku.php?id=en:bs2_getantipassbackzonestatus

Last update: **2016/07/12 10:21**