

Table of Contents

BS2_GetUserDatasExFromDir	1
Declaration	1
Parameter	1
Return Value	1
See Also	1

BS2_GetUserDatasExFromDir

Gets the user information of the given user ID from storage path in device.

Declaration

```
#include "BS_API.h"

int BS2_GetUserDatasExFromDir(void* context, const char* szDir, char* uids,
uint32_t uidCount, BS2UserBlobEx* userBlob, BS2_USER_MASK userMask);
```

[See BS2UserBlobEx Structure](#)

Parameter

- [In] *context* : Context
- [In] *szDir* : Storage path in device
- [In] *uids* : User ID list trying to get
- [In] *uidCount* : Number of user ID
- [Out] *userBlob* : Pointer to store the user information
- [In] *userMask* : User Mask

Return Value

If successfully done, BS_SDK_SUCCESS will be returned.
If there is an error, the corresponding error code will be returned.

See Also

[BS2_GetUserDatabaseInfoFromDir](#)

[BS2_GetUserListFromDir](#)

[BS2_GetUserInfosFromDir](#)

[BS2_GetUserDatasFromDir](#)

[BS2_GetUserInfosExFromDir](#)

From:

<http://kb.supremainc.com/bs2sdk/> - **BioStar 2 Device SDK**

Permanent link:

http://kb.supremainc.com/bs2sdk/doku.php?id=en:bs2_getuserdatasexfromdir&rev=1506657085

Last update: **2017/09/29 12:51**

