

# Table of Contents

<b><i>BS2_SetAccessGroupEntranceLimit</i></b> .....	1
Declaration .....	1
Parameter .....	1
Return Value .....	1
See Also .....	1

## BS2\_SetAccessGroupEntranceLimit

Configures access group entrance limit.

### Declaration

```
#include "BS_API.h"

int BS2_SetAccessGroupEntranceLimit(void* context, BS2_DEVICE_ID deviceId,
const BS2DeviceZoneAGEntranceLimit* agEntranceLimits, uint32_t
agEntranceLimitCount);
```

[See BS2DeviceZoneAGEntranceLimit Structure](#)

### Parameter

- [In] *context* : Context
- [In] *deviceId* : Device ID
- [In] *agEntranceLimits* : Device zone access group entrance limit list
- [In] *agEntranceLimitCount* : Number of device zone access group entrance limit list

### Return Value

If successfully done, BS\_SDK\_SUCCESS will be returned.  
If there is an error, the corresponding error code will be returned.

### See Also

[BS2\\_GetAccessGroupEntranceLimit](#)  
[BS2\\_GetAllAccessGroupEntranceLimit](#)  
[BS2\\_RemoveAccessGroupEntranceLimit](#)  
[BS2\\_RemoveAllAccessGroupEntranceLimit](#)

From:

<http://kb.supremainc.com/bs2sdk/> - **BioStar Device SDK**

Permanent link:

[http://kb.supremainc.com/bs2sdk./doku.php?id=en:bs2\\_setaccessgroupentancelimit&rev=1504684548](http://kb.supremainc.com/bs2sdk./doku.php?id=en:bs2_setaccessgroupentancelimit&rev=1504684548)

Last update: **2017/09/06 16:55**