

BS2_GetAllLiftLockUnlockZoneStatus 1
..... 1
..... 1
..... 1
..... 1

BS2_GetAllLiftLockUnlockZoneStatus


[+ 2.7.0] Lift / 가 .

```
#include "BS_API.h"

int BS2_GetAllLiftLockUnlockZoneStatus(void* context, uint32_t deviceId,
BS2ZoneStatus** zoneStatusObj, uint32_t* numZoneStatus);
```

[BS2ZoneStatus](#)

- [In] *context* : Context
- [In] *deviceId* :
- [Out] *zoneStatusObj* : zone status
- [Out] *numZoneStatus* : zone status



BS_SDK_SUCCESS , 가

- [BS2_GetLiftLockUnlockZone](#)
- [BS2_GetAllLiftLockUnlockZone](#)
- [BS2_GetLiftLockUnlockZoneStatus](#)
- [BS2_SetLiftLockUnlockZone](#)
- [BS2_SetLiftLockUnlockZoneAlarm](#)

[BS2_RemoveLiftLockUnlockZone](#)

[BS2_RemoveAllLiftLockUnlockZone](#)

From:

<http://kb.supremainc.com/bs2sdk/> - **BioStar Device SDK**

Permanent link:

http://kb.supremainc.com/bs2sdk./doku.php?id=ko:bs2_getallliftlockunlockzonestatus

Last update: **2020/07/21 21:06**