

BS2_GetLiftLockUnlockZone 1
..... 1
..... 1
..... 1
..... 1

BS2_GetLiftLockUnlockZone

[+ 2.7.0] Lift / 가 .

```
#include "BS_API.h"

int BS2_GetLiftLockUnlockZone(void* context, uint32_t deviceId, uint32_t* zoneIds, uint32_t zoneIdCount, BS2LiftLockUnlockZone** zoneObj, uint32_t* numZone);
```

[BS2LiftLockUnlockZone](#)

- [In] *context* : Context
- [In] *deviceId* :
- [In] *zoneIds* : 가 Lift lock/unlock zone id
- [In] *zoneIdCount* : Lift lock/unlock zone id
- [Out] *zoneObj* : Lift lock/unlock zone
- [Out] *numZone* : Lift lock/unlock zone



BS_SDK_SUCCESS , 가

[BS2_GetAllLiftLockUnlockZone](#)
[BS2_GetLiftLockUnlockZoneStatus](#)

[BS2_GetAllLiftLockUnlockZoneStatus](#)
[BS2_SetLiftLockUnlockZone](#)
[BS2_SetLiftLockUnlockZoneAlarm](#)
[BS2_RemoveLiftLockUnlockZone](#)
[BS2_RemoveAllLiftLockUnlockZone](#)

From:

<https://kb.supremainc.com/bs2sdk/> - **BioStar Device SDK**

Permanent link:

https://kb.supremainc.com/bs2sdk/doku.php?id=ko:bs2_getliftlockunlockzone

Last update: **2020/07/21 21:04**