

BS2_SetLiftLockUnlockZoneAlarm 1
..... 1
..... 1
..... 1
..... 1

[Zone Control API](#) > [BS2_SetLiftLockUnlockZoneAlarm](#)

BS2_SetLiftLockUnlockZoneAlarm

[+ 2.7.0] Lift

```
#include "BS_API.h"
```

```
int BS2_SetLiftLockUnlockZoneAlarm(void* context, uint32_t deviceId, uint8_t  
alarmed, uint32_t* zoneIds, uint32_t zoneIdCount);
```

- [In] *context* : Context
- [In] *deviceId* :
- [In] *alarmed* :
- [In] *zoneIds* : Lift lock/unlock zone id
- [In] *zoneIdCount* : Lift lock/unlock zone id

BS_SDK_SUCCESS , 가

[BS2_GetLiftLockUnlockZone](#)
[BS2_GetAllLiftLockUnlockZone](#)
[BS2_GetLiftLockUnlockZoneStatus](#)
[BS2_GetAllLiftLockUnlockZoneStatus](#)
[BS2_SetLiftLockUnlockZone](#)
[BS2_RemoveLiftLockUnlockZone](#)
[BS2_RemoveAllLiftLockUnlockZone](#)

From:
<http://kb.supremainc.com/bs2sdk/> - **BioStar Device SDK**

Permanent link:
http://kb.supremainc.com/bs2sdk./doku.php?id=ko:bs2_setliftlockunlockzonealarm

Last update: **2020/07/21 21:08**

