

BS2_DeActivateFloor 1
..... 1
..... 1
..... 1
..... 1

BS2_DeActivateFloor

Floor가 , Floor가 .

```
#include "BS_API.h"

int BS2_DeActivateFloor(void* context, uint32_t deviceId, BS2_FLOOR_FLAG
flag, BS2_LIFT_ID liftID, uint16_t* floorIndexs, uint8_t floorIndexCount);
```

- [In] *context* : Context
- [In] *deviceId* :
- [In] *flag* : 가 floor
- [In] *liftID* : lift ID
- [In] *floorIndexs* : floor Index
- [In] *floorIndexCount* : floor Index

BS_SDK_SUCCESS , 가

- [BS2_GetLift](#)
- [BS2_GetAllLift](#)
- [BS2_GetLiftStatus](#)
- [BS2_GetAllLiftStatus](#)
- [BS2_SetLift](#)
- [BS2_SetLiftAlarm](#)
- [BS2_RemoveLift](#)
- [BS2_RemoveAllLift](#)
- [BS2_ReleaseFloor](#)
- [BS2_ActivateFloor](#)

From:

<http://kb.supremainc.com/bs2sdk/> - **BioStar Device SDK**

Permanent link:

http://kb.supremainc.com/bs2sdk/doku.php?id=ko:bs2_deactivatefloor

Last update: **2017/06/28 11:41**