

**BS2\_RemoveIntrusionAlarmZone** ..... 1  
..... 1  
..... 1  
..... 1  
..... 1

[Zone Control API](#) > [BS2\\_RemoveIntrusionAlarmZone](#)

---

## BS2\_RemoveIntrusionAlarmZone

```
#include "BS_API.h"

int BS2_RemoveIntrusionAlarmZone(void* context, uint32_t deviceId, uint32_t* zoneIds, uint32_t zoneIdCount);
```

- [In] *context* : Context
- [In] *deviceId* :
- [In] *zoneIds* : fire alarm zone id
- [In] *zoneIdCount* : fire alarm zone id

BS\_SDK\_SUCCESS , 가

[BS2\\_GetIntrusionAlarmZone](#)  
[BS2\\_GetIntrusionAlarmZoneStatus](#)  
[BS2\\_GetAllIntrusionAlarmZoneStatus](#)  
[BS2\\_SetIntrusionAlarmZone](#)  
[BS2\\_SetIntrusionAlarmZoneAlarm](#)  
[BS2\\_RemoveAllIntrusionAlarmZone](#)  
[BS2\\_SetIntrusionAlarmZoneArm](#)

From:

<http://kb.supremainc.com/bs2sdk/> - **BioStar Device SDK**

Permanent link:

[http://kb.supremainc.com/bs2sdk/doku.php?id=ko:bs2\\_removeintrusionalarmzone&rev=1504243864](http://kb.supremainc.com/bs2sdk/doku.php?id=ko:bs2_removeintrusionalarmzone&rev=1504243864)

Last update: **2017/09/01 14:31**