

BS2_SetDoor 1
..... 1
..... 1
..... 1
..... 1

BS2_SetDoor

```
#include "BS_API.h"

int BS2_SetDoor(void* context, uint32_t deviceId, BS2Door* doors, uint32_t doorCount);
```

BS2Door

- [In] *context* : Context
- [In] *deviceId* :
- [In] *doors* : door
- [In] *doorCount* : door

BS_SDK_SUCCESS , 가

- [BS2_GetDoor](#)
- [BS2_GetAllDoor](#)
- [BS2_GetDoorStatus](#)
- [BS2_GetAllDoorStatus](#)
- [BS2_SetDoorAlarm](#)
- [BS2_RemoveDoor](#)
- [BS2_RemoveAllDoor](#)
- [BS2_ReleaseDoor](#)
- [BS2_LockDoor](#)
- [BS2_UnlockDoor](#)

From:

<https://kb.supremainc.com/bs2sdk/> - **BioStar Device SDK**

Permanent link:

https://kb.supremainc.com/bs2sdk/doku.php?id=ko:bs2_setdoor

Last update: **2016/07/12 09:16**