

**BS2\_SetIntrusionAlarmZoneAlarm** ..... 1  
..... 1  
..... 1  
..... 1  
..... 1

[Zone Control API](#) > [BS2\\_SetIntrusionAlarmZoneAlarm](#)

---

## BS2\_SetIntrusionAlarmZoneAlarm

```
#include "BS_API.h"

int BS2_SetIntrusionAlarmZoneAlarm(void* context, uint32_t deviceId, uint8_t
alarmed, uint32_t* zoneIds, uint32_t zoneIdCount);
```

- [In] *context* : Context
- [In] *deviceId* :
- [In] *alarmed* :
- [In] *zoneIds* : intrusion alarm zone id
- [In] *zoneIdCount* : intrusion alarm zone id

BS\_SDK\_SUCCESS , 가

[BS2\\_GetIntrusionAlarmZone](#)  
[BS2\\_GetIntrusionAlarmZoneStatus](#)  
[BS2\\_GetAllIntrusionAlarmZoneStatus](#)  
[BS2\\_SetIntrusionAlarmZone](#)  
[BS2\\_RemoveIntrusionAlarmZone](#)  
[BS2\\_RemoveAllIntrusionAlarmZone](#)  
[BS2\\_SetIntrusionAlarmZoneArm](#)

From:  
<https://kb.supremainc.com/bs2sdk/> - **BioStar Device SDK**

Permanent link:  
[https://kb.supremainc.com/bs2sdk./doku.php?id=ko:bs2\\_setintrusionalarmzonealarm&rev=1504234380](https://kb.supremainc.com/bs2sdk./doku.php?id=ko:bs2_setintrusionalarmzonealarm&rev=1504234380)

Last update: **2017/09/01 11:53**