

Table of Contents


How to Configure XPass D2	1
Adding as a Slave Device	1
Using the device as a Wiegand Reader	1

How to Configure XPass D2

XPass D2 is a new device introduced with BioStar 2.6. It is a dummy reader for reading cards, which means it doesn't perform data matching on itself. The device can be used as a slave device, or a Wiegand reader to send Wiegand output. The device sends out a Wiegand signal with the default 26bit format and the Wiegand configuration will be done with a separate tool Device manager. Please refer to the article: [How to use Suprema Device Manager App](#)

Adding as a Slave Device


You will need a master device to add the slave D2 device. Refer to the article below to learn how to search for a slave device. [RS485 Mode \(Master, Default, Slave\)](#)




Using the device as a Wiegand Reader

If you already have used the device as a slave device before, you must reset the device to use it as a Wiegand reader (sending Wiegand output).


1. Delete the device(slave device) from BioStar 2 client.



2. Detach the metal bracket from the device.
3. Press the reset button.



4. Use the device as a Wiegand reader by adding it as a **Wiegand Device** on a master device.



You cannot use the device as a slave device and use Wiegand output at the same time.

From:
<https://kb.supremainc.com/knowledge/> -

Permanent link:
https://kb.supremainc.com/knowledge/doku.php?id=en:how_to_configure_xpass_d2

Last update: **2021/12/17 10:26**