

# Table of Contents

<b>BS2_GetAccessLevel</b> .....	1
Declaration .....	1
Parameter .....	1
Return Value .....	1
See Also .....	1

[Access Control API](#) > [BS2\\_GetAccessLevel](#)

---

## BS2\_GetAccessLevel

Retrieves selected access levels.

### Declaration

```
#include "BS_API.h"

int BS2_GetAccessLevel(void* context, uint32_t deviceId, uint32_t*
accessLevelIds, uint32_t accessLevelIdCount, BS2AccessLevel**
accessLevelObj, uint32_t* numAccessLevel);
```

[See BS2AccessLevel Structure](#)

### Parameter

- [In] *context* : Context
- [In] *deviceId* : Device ID
- [In] *accessLevelIds* : List of access level IDs to retrieve
- [In] *accessLevelIdCount* : Number of access levels to retrieve
- [Out] *accessLevelObj* : Access level list pointer
- [Out] *numAccessLevel* : Number of access levels

#### NOTE

The *accessLevelObj* variable needs to return the memory to the system by the [BS2\\_ReleaseObject](#) function after being used.

### Return Value

If successfully done, `BS_SDK_SUCCESS` will be returned.  
If there is an error, the corresponding error code will be returned.

### See Also

[BS2\\_GetAllAccessLevel](#)

[BS2\\_SetAccessLevel](#)

[BS2\\_RemoveAccessLevel](#)

[BS2\\_RemoveAllAccessLevel](#)

From:

<http://kb.supremainc.com/bs2sdk/> - **BioStar 2 Device SDK**

Permanent link:

[http://kb.supremainc.com/bs2sdk/doku.php?id=en:bs2\\_getaccesslevel](http://kb.supremainc.com/bs2sdk/doku.php?id=en:bs2_getaccesslevel)

Last update: **2017/03/01 18:02**