

# Table of Contents

<b>BS2_GetRS485ConfigEx</b> .....	1
Declaration .....	1
Parameter .....	1
Return Value .....	1

[Configuration API](#) > [BS2\\_GetRS485ConfigEx](#)

---

## BS2\_GetRS485ConfigEx

In case of CoreStation, retrieves RS-485 network settings from the device.

### Declaration

```
#include "BS_API.h"

int BS2_GetRS485ConfigEx(void* context, uint32_t deviceId, BS2Rs485ConfigEX* config);
```

[See BS2Rs485ConfigEX Structure](#)

### Parameter

- [In] *context* : Context
- [In] *deviceId* : Device ID
- [Out] *config* : RS-485 network configurations pointer

### Return Value

If successfully done, BS\_SDK\_SUCCESS will be returned.  
If there is an error, the corresponding error code will be returned.

From:  
<http://kb.supremainc.com/bs2sdk/> - **BioStar Device SDK**

Permanent link:  
[http://kb.supremainc.com/bs2sdk/doku.php?id=en:bs2\\_getrs485configex](http://kb.supremainc.com/bs2sdk/doku.php?id=en:bs2_getrs485configex)

Last update: **2018/03/12 08:46**