

BS2_GetFireAlarmZoneStatus 1
..... 1
..... 1
..... 1
..... 1

BS2_GetFireAlarmZoneStatus


가 .

```
#include "BS_API.h"

int BS2_GetFireAlarmZoneStatus(void* context, uint32_t deviceId, uint32_t* zoneIds, uint32_t zoneIdCount, BS2ZoneStatus** zoneStatusObj, uint32_t* numZoneStatus);
```

BS2ZoneStatus

- [In] *context* : Context
- [In] *deviceId* :
- [In] *zoneIds* : 가 fire alarm zone id
- [In] *zoneIdCount* : fire alarm zone id
- [Out] *zoneStatusObj* : zone status
- [Out] *numZoneStatus* : zone status



BS_SDK_SUCCESS , 가

[BS2_GetFireAlarmZone](#)
[BS2_GetAllFireAlarmZone](#)

[BS2_GetAllFireAlarmZoneStatus](#)
[BS2_SetFireAlarmZone](#)
[BS2_SetFireAlarmZoneAlarm](#)
[BS2_RemoveFireAlarmZone](#)
[BS2_RemoveAllFireAlarmZone](#)

From:

<http://kb.supremainc.com/bs2sdk/> - **BioStar 2 Device SDK**

Permanent link:

http://kb.supremainc.com/bs2sdk./doku.php?id=ko:bs2_getfirealarmzonestatus

Last update: **2016/07/12 10:07**