

BS2_GetLiftLockUnlockZoneStatus 1
..... 1
..... 1
..... 1
..... 1

BS2_GetLiftLockUnlockZoneStatus


[+ 2.7.0] Lift / 가 .

```
#include "BS_API.h"

int BS2_GetLiftLockUnlockZoneStatus(void* context, uint32_t deviceId,
uint32_t* zoneIds, uint32_t zoneIdCount, BS2ZoneStatus** zoneStatusObj,
uint32_t* numZoneStatus);
```

[BS2ZoneStatus](#)

- [In] *context* : Context
- [In] *deviceId* :
- [In] *zoneIds* : 가 Lift lock/unlock zone id
- [In] *zoneIdCount* : Lift lock/unlock zone id
- [Out] *zoneStatusObj* : zone status
- [Out] *numZoneStatus* : zone status



BS_SDK_SUCCESS , 가

[BS2_GetLiftLockUnlockZone](#)
[BS2_GetAllLiftLockUnlockZone](#)

[BS2_GetAllLiftLockUnlockZoneStatus](#)
[BS2_SetLiftLockUnlockZone](#)
[BS2_SetLiftLockUnlockZoneAlarm](#)
[BS2_RemoveLiftLockUnlockZone](#)
[BS2_RemoveAllLiftLockUnlockZone](#)

From:

<http://kb.supremainc.com/bs2sdk/> - **BioStar 2 Device SDK**

Permanent link:

http://kb.supremainc.com/bs2sdk/doku.php?id=ko:bs2_getliftlockunlockzonestatus

Last update: **2020/08/07 12:50**