

# Table of Contents

<b>BS2_GetAllDoorStatus</b> .....	1
Declaration .....	1
Parameter .....	1
Return Value .....	1
See Also .....	1

[Door Control API](#) > [BS2\\_GetAllDoorStatus](#)

---

## BS2\_GetAllDoorStatus

Retrieves the status of all doors.

### Declaration

```
#include "BS_API.h"

int BS2_GetAllDoorStatus(void* context, uint32_t deviceId, BS2DoorStatus**
doorStatusObj, uint32_t* numDoorStatus);
```

[See BS2DoorStatus Structure](#)

### Parameter

- [In] *context* : Context
- [In] *deviceId* : Device ID
- [Out] *doorStatusObj* : Door status list pointer
- [Out] *numDoorStatus* : Number of door status records

#### NOTE

The *doorStatusObj* variable needs to return the memory to the system by the [BS2\\_ReleaseObject](#) function after being used.

### Return Value

If successfully done, `BS_SDK_SUCCESS` will be returned.  
If there is an error, the corresponding error code will be returned.

### See Also

[BS2\\_GetDoor](#)  
[BS2\\_GetAllDoor](#)  
[BS2\\_GetDoorStatus](#)  
[BS2\\_SetDoor](#)

BS2\_SetDoor  
BS2\_SetDoorAlarm  
BS2\_RemoveDoor  
BS2\_RemoveAllDoor  
BS2\_ReleaseDoor  
BS2\_LockDoor  
BS2\_UnlockDoor

From:

<http://kb.supremainc.com/bs2sdk/> - **BioStar 2 Device SDK**

Permanent link:

[http://kb.supremainc.com/bs2sdk/doku.php?id=en:bs2\\_getalldoorstatus](http://kb.supremainc.com/bs2sdk/doku.php?id=en:bs2_getalldoorstatus)

Last update: **2016/08/08 15:16**