

Table of Contents

BS2_GetInterlockZone	1
Declaration	1
Parameter	1
Return Value	1
See Also	1

[Zone Control API](#) > [BS2_GetInterlockZone](#)

BS2_GetInterlockZone

[+ V2.6.0] Gets selected Interlock zones.

Declaration

```
#include "BS_API.h"

int BS2_GetInterlockZone(void* context, BS2_DEVICE_ID deviceId,
BS2InterlockZoneBlob* zoneBlob, uint32_t* numZone);
```

[BS2InterlockZoneBlob Structure](#)

Parameter

- [In] *context* : Context
- [In] *deviceId* : Device ID
- [Out] *zoneBlob* : Interlock zone list pointer
- [Out] *numZone* : Number of Interlock zones

NOTE

The zoneObj variable needs to return the memory to the system by the [BS2_ReleaseObject](#) function after being used.

Return Value

If successfully done, BS_SDK_SUCCESS will be returned.
If there is an error, the corresponding error code will be returned.

See Also

[BS2_GetInterlockZoneStatus](#)
[BS2_GetAllInterlockZoneStatus](#)
[BS2_SetInterlockZone](#)
[BS2_SetInterlockZoneAlarm](#)

[BS2_RemoveInterlockZone](#)
[BS2_RemoveAllInterlockZone](#)

From:

<http://kb.supremainc.com/bs2sdk/> - **BioStar 2 Device SDK**

Permanent link:

http://kb.supremainc.com/bs2sdk./doku.php?id=en:bs2_getinterlockzone&rev=1521006146

Last update: **2018/03/14 14:42**