

## Table of Contents

<b>BS2_QueryDeviceLicense</b> .....	1
Declaration .....	1
Parameter .....	1
Return Value .....	2
Sample Code(C++) .....	2
Sample Code (C#) .....	2

SDK API > [BS2\\_QueryDeviceLicense](#)

## BS2\_QueryDeviceLicense

[+ 2.9.1] Get the device license activation/deactivation status of the device connected as master-slave.

This feature is available only on devices that support the device license activation feature, and the devices that support the feature are listed below.

Supported devices	Firmware
XS2-Finger	V1.2.0
XS2-Card	V1.2.0
BS3	V1.1.0

### Declaration

```
#include "BS_API.h"

int BS2_QueryDeviceLicense(void* context, uint32_t deviceId,
BS2_LICENSE_TYPE licenseType, BS2LicenseResult** outResultObj, uint32_t*
outNumOfResult);
```

[See BS2LicenseResult Structure](#)

### Parameter

- [In] *context* : Context
- [In] *deviceId* : Device Identifier
- [In] *licenseType* : Device License Type

Value	Description
0x0000	None
0x0001	Visual QR

- [Out] *outResultObj* : Pointer to structure to receive device license activation result
- [Out] *outNumOfResult* : Number of device license activation result structures

#### NOTE

The *outResultObj* parameter must be used and then returned memory to the system via the [BS2\\_ReleaseObject](#) function.

## Return Value

If successfully done, BS\_SDK\_SUCCESS will be returned. If there is an error, the corresponding error code will be returned.

## Sample Code(C++)

sample\_setdebugfilelogex.cpp

```
const char* CURRENT_DIR = ".";
const int MAX_SIZE_LOG_FILE = 100; // 100MB
int sdkResult = BS2_SetDebugFileLogEx(DEBUG_LOG_ALL, DEBUG_MODULE_ALL,
CURRENT_DIR, MAX_SIZE_LOG_FILE);
if (BS_SDK_SUCCESS != sdkResult)
{
    printf("BS2_SetDebugFileLogEx call failed: %d", sdkResult);
    return;
}
```

## Sample Code (C#)

sample\_setdebugfilelogex.cs

```
const string CURRENT_DIR = ".";
const int MAX_SIZE_LOG_FILE = 100; // 100MB
IntPtr ptrDir = Marshal.StringToHGlobalAnsi(CURRENT_DIR);
result =
(BS2ErrorCode)API.BS2_SetDebugFileLogEx(Constants.DEBUG_LOG_OPERATION_A
LL, Constants.DEBUG_MODULE_ALL, ptrDir, MAX_SIZE_LOG_FILE);
Marshal.FreeHGlobal(ptrDir);
if (result != BS2ErrorCode.BS_SDK_SUCCESS)
{
    Console.WriteLine("Got error({0}).", result);
    return;
}
```

From:

<https://kb.supremainc.com/bs2sdk/> - BioStar 2 Device SDK

Permanent link:

[https://kb.supremainc.com/bs2sdk/doku.php?id=en:bs2\\_querydevicelicense&rev=1677563357](https://kb.supremainc.com/bs2sdk/doku.php?id=en:bs2_querydevicelicense&rev=1677563357)

Last update: **2023/02/28 14:49**