

# Table of Contents

|                               |   |
|-------------------------------|---|
| <b>BS2_ReleaseFloor</b> ..... | 1 |
| Declaration .....             | 1 |
| Parameter .....               | 1 |
| Return Value .....            | 1 |
| See Also .....                | 1 |

[Lift Control API](#) > [BS2\\_ReleaseFloor](#)

---

## BS2\_ReleaseFloor

Releases the activate/deactivate flag of the lift status. This initializes the priorities set to the lift.

### Declaration

```
#include "BS_API.h"

int BS2_ReleaseFloor(void* context, uint32_t deviceId, BS2_FLOOR_FLAG flag,
BS2_LIFT_ID liftID, uint16_t* floorIndexs, uint8_t floorIndexCount);
```

### Parameter

- [In] *context* : Context
- [In] *deviceId* : Device ID
- [In] *flag* : Priority of the floor to release
- [In] *liftID* : Lift ID
- [In] *floorIndexs* : List of floor indexes
- [In] *floorIndexCount* : Number of floor indexes

### Return Value

If successfully done, `BS_SDK_SUCCESS` will be returned.  
If there is an error, the corresponding error code will be returned.

### See Also

[BS2\\_GetLift](#)  
[BS2\\_GetAllLift](#)  
[BS2\\_GetLiftStatus](#)  
[BS2\\_GetAllLiftStatus](#)  
[BS2\\_SetLift](#)  
[BS2\\_SetLiftAlarm](#)  
[BS2\\_RemoveLift](#)  
[BS2\\_RemoveAllLift](#)  
[BS2\\_ActivateFloor](#)  
[BS2\\_DeActivateFloor](#)

From:

<http://kb.supremainc.com/bs2sdk/> - **BioStar 2 Device SDK**

Permanent link:

[http://kb.supremainc.com/bs2sdk/doku.php?id=en:bs2\\_releasefloor](http://kb.supremainc.com/bs2sdk/doku.php?id=en:bs2_releasefloor)

Last update: **2017/06/28 10:51**