

Table of Contents

BS2_RemoveAllFloorLevel	1
Declaration	1
Parameter	1
Return Value	1
See Also	1

[Lift Control API](#) > [BS2_RemoveAllFloorLevel](#)

BS2_RemoveAllFloorLevel

Removes all floor levels.

Declaration

```
#include "BS_API.h"

int BS2_RemoveAllFloorLevel(void* context, uint32_t deviceId);
```

Parameter

- [In] *context* : Context
- [In] *deviceId* : Device ID

Return Value

If successfully done, BS_SDK_SUCCESS will be returned.
If there is an error, the corresponding error code will be returned.

See Also

[BS2_GetFloorLevel](#)
[BS2_GetAllFloorLevel](#)
[BS2_SetFloorLevel](#)
[BS2_RemoveFloorLevel](#)

From:

<http://kb.supremainc.com/bs2sdk/> - **BioStar 2 Device SDK**

Permanent link:

http://kb.supremainc.com/bs2sdk/doku.php?id=en:bs2_removeallfloorlevel

Last update: **2017/06/28 10:53**