

# Table of Contents

<b>BS2_RemoveFireAlarmZone</b> .....	1
Declaration .....	1
Parameter .....	1
Return Value .....	1
See Also .....	1

[Zone Control API](#) > [BS2\\_RemoveFireAlarmZone](#)

---

## BS2\_RemoveFireAlarmZone

Removes selected Fire Alarm zones.

### Declaration

```
#include "BS_API.h"

int BS2_RemoveFireAlarmZone(void* context, uint32_t deviceId, uint32_t*
zoneIds, uint32_t zoneIdCount);
```

### Parameter

- [In] *context* : Context
- [In] *deviceId* : Device ID
- [In] *zoneIds* : List of Fire Alarm zone IDs to remove
- [In] *zoneIdCount* : Number of Fire Alarm zones to remove

### Return Value

If successfully done, BS\_SDK\_SUCCESS will be returned.

If there is an error, the corresponding error code will be returned.

### See Also

[BS2\\_GetFireAlarmZone](#)

[BS2\\_GetAllFireAlarmZone](#)

[BS2\\_GetFireAlarmZoneStatus](#)

[BS2\\_GetAllFireAlarmZoneStatus](#)

[BS2\\_SetFireAlarmZone](#)

[BS2\\_SetFireAlarmZoneAlarm](#)

[BS2\\_RemoveAllFireAlarmZone](#)

From:

<https://kb.supremainc.com/bs2sdk/> - **BioStar Device SDK**

Permanent link:

[https://kb.supremainc.com/bs2sdk/doku.php?id=en:bs2\\_removefirealarmzone](https://kb.supremainc.com/bs2sdk/doku.php?id=en:bs2_removefirealarmzone)

Last update: **2017/03/01 17:22**

