

# Table of Contents

<b>BS2_SetSlaveBaudrate</b> .....	1
Declaration .....	1
Parameter .....	1
Return Value .....	1

[Slave Control API](#) > [BS2\\_SetSlaveBaudrate](#)

---

## BS2\_SetSlaveBaudrate

[+ 2.9.8] Set the RS-485 baud rate of a slave device connected to a master device. To reconnect with the slave, the RS-485 baud rate of the master device must also be changed to match the baud rate of the slave.

### Declaration

```
#include "BS_API.h"

int BS2_SetSlaveBaudrate(IntPtr context, UInt32 deviceId, UInt32 slaveId,
    UInt32 baudrate);
```

### Parameter

- [In] *context* : Context
- [In] *deviceId* : Device ID
- [In] *slaveId* : Slave device ID
- [In] *baudrate* : RS-485 baud rate

### Return Value

If successfully done, `BS_SDK_SUCCESS` will be returned.  
If there is an error, the corresponding error code will be returned.

From:

<https://kb.supremainc.com/bs2sdk/> - **BioStar 2 Device SDK**

Permanent link:

[https://kb.supremainc.com/bs2sdk./doku.php?id=en:bs2\\_setslavebaudrate](https://kb.supremainc.com/bs2sdk./doku.php?id=en:bs2_setslavebaudrate)

Last update: **2024/10/23 16:27**