

Table of Contents

BS2_SetSlaveExDevice	1
Declaration	1
Parameter	1
Return Value	1
See Also	1

[Slave Control API](#) > [BS2_SetSlaveDevice](#)

BS2_SetSlaveExDevice

In case of CoreStation, Add/Modify/Delete a slave device from the master device.

Declaration

```
#include "BS_API.h"

int BS2_SetSlaveExDevice(void* context, uint32_t deviceId, uint32_t
channelPort, BS2Rs485SlaveDeviceEX* slaveDevices, uint32_t
slaveDeviceCount);
```

[See BS2Rs485SlaveDevice Structure](#)

Parameter

- [In] *context* : Context
- [In] *deviceId* : Device ID
- [In] *channelPort* : Channel port
- [In] *slaveDevices* : List of slave device
- [In] *slaveDeviceCount* : Number of slave device

Return Value

If successfully done, BS_SDK_SUCCESS will be returned.

If there is an error, the corresponding error code will be returned.

See Also

[BS2_GetSlaveExDevice](#)

From:

<http://kb.supremainc.com/bs2sdk/> - **BioStar 2 Device SDK**

Permanent link:

http://kb.supremainc.com/bs2sdk/doku.php?id=en:bs2_setslaveexdevice

Last update: **2017/09/04 16:19**

