

BS2_GetAllIntrusionAlarmZoneStatus 1
..... 1
..... 1
..... 1
..... 1

BS2_GetAllIntrusionAlarmZoneStatus


가 .

```
#include "BS_API.h"

int BS2_GetAllIntrusionAlarmZoneStatus(void* context, BS2_DEVICE_ID
deviceId, BS2ZoneStatus** zoneStatusObj, uint32_t* numZoneStatus);
```

BS2ZoneStatus

- [In] *context* : Context
- [In] *deviceId* :
- [In] *zoneIds* : 가 id
- [In] *zoneIdCount* : id
- [Out] *zoneStatusObj* : zone status
- [Out] *numZoneStatus* : zone status



BS_SDK_SUCCESS , 가

- [BS2_GetIntrusionAlarmZone](#)
- [BS2_GetIntrusionAlarmZoneStatus](#)
- [BS2_SetIntrusionAlarmZone](#)

[BS2_SetIntrusionAlarmZoneAlarm](#)
[BS2_RemoveIntrusionAlarmZone](#)
[BS2_RemoveAllIntrusionAlarmZone](#)
[BS2_SetIntrusionAlarmZoneArm](#)

From:

<http://kb.supremainc.com/bs2sdk/> - **BioStar 2 Device SDK**

Permanent link:

http://kb.supremainc.com/bs2sdk./doku.php?id=ko:bs2_getallintrusionalarmzonestatus

Last update: **2018/03/21 14:58**