

BS2_GetAllIntrusionAlarmZoneStatus 1
..... 1
..... 1
..... 1
..... 1

BS2_GetAllIntrusionAlarmZoneStatus

가 .

```
#include "BS_API.h"

int BS2_GetAllIntrusionAlarmZoneStatus(void* context, uint32_t deviceId,
uint32_t* zoneIds, uint32_t zoneIdCount, BS2ZoneStatus** zoneStatusObj,
uint32_t* numZoneStatus);
```

BS2ZoneStatus

- [In] *context* : Context
- [In] *deviceId* :
- [In] *zoneIds* : 가 fire alarm zone id
- [In] *zoneIdCount* : fire alarm zone id
- [Out] *zoneStatusObj* : zone status
- [Out] *numZoneStatus* : zone status

zoneStatusObj [BS2_ReleaseObject](#)

BS_SDK_SUCCESS , 가

[BS2_GetIntrusionAlarmZone](#)
[BS2_GetIntrusionAlarmZoneStatus](#)

[BS2_SetIntrusionAlarmZone](#)
[BS2_SetIntrusionAlarmZoneAlarm](#)
[BS2_RemoveIntrusionAlarmZone](#)
[BS2_RemoveAllIntrusionAlarmZone](#)
[BS2_SetIntrusionAlarmZoneArm](#)

From:

<http://kb.supremainc.com/bs2sdk/> - **BioStar 2 Device SDK**

Permanent link:

http://kb.supremainc.com/bs2sdk/doku.php?id=ko:bs2_getallintrusionalarmzonestatus&rev=1504231875

Last update: **2017/09/01 11:11**