

BS2_GetDeviceZone 1
..... 1
..... 1
..... 1
..... 1

BS2_GetDeviceZone

Ethernet 가 .

```
#include "BS_API.h"

int BS2_GetDeviceZone(void* context, BS2_DEVICE_ID deviceId, const
BS2_DEVICE_ZONE_TABLE_ID* Ids, uint32_t IdCount, BS2DeviceZone**
deviceZoneObj, uint32_t* numDeviceZone);
```

[BS2DeviceZone](#)

- [In] *context* : Context
- [In] *deviceId* :
- [In] *Ids* : 가 device zone id
- [In] *IdCount* : device zone id
- [Out] *deviceZoneObj* : device zone
- [Out] *numDeviceZone* : device zone



BS_SDK_SUCCESS , 가

[BS2_GetAllDeviceZone](#)
[BS2_SetDeviceZone](#)

[BS2_RemoveDeviceZone](#)
[BS2_RemoveAllDeviceZone](#)
[BS2_SetDeviceZoneAlarm](#)

From:

<http://kb.supremainc.com/bs2sdk/> - **BioStar 2 Device SDK**

Permanent link:

http://kb.supremainc.com/bs2sdk/doku.php?id=ko:bs2_getdevicezone&rev=1504530215

Last update: **2017/09/04 22:03**