

BS2_GetInterlockZoneStatus 1
..... 1
..... 1
..... 1
..... 1

BS2_GetInterlockZoneStatus


가 .

```
#include "BS_API.h"

int BS2_GetInterlockZoneStatus(void* context, uint32_t deviceId, uint32_t*
zoneIds, uint32_t zoneIdCount, BS2ZoneStatus** zoneStatusObj, uint32_t*
numZoneStatus);
```

BS2ZoneStatus

- [In] *context* : Context
- [In] *deviceId* :
- [In] *zoneIds* : 가 id
- [In] *zoneIdCount* : id
- [Out] *zoneStatusObj* : zone status
- [Out] *numZoneStatus* : zone status



BS_SDK_SUCCESS , 가

[BS2_GetInterlockZone](#)
[BS2_GetAllInterlockZoneStatus](#)

[BS2_SetInterlockZone](#)
[BS2_SetInterlockZoneAlarm](#)
[BS2_RemoveInterlockZone](#)
[BS2_RemoveAllInterlockZone](#)
[BS2_SetInterlockZoneArm](#)

From:

<http://kb.supremainc.com/bs2sdk/> - **BioStar 2 Device SDK**

Permanent link:

http://kb.supremainc.com/bs2sdk./doku.php?id=ko:bs2_getinterlockzonestatus&rev=1520397196

Last update: **2018/03/07 13:33**