

BS2_RemoveDeviceZone 1
..... 1
..... 1
..... 1
..... 1

BS2_RemoveDeviceZone

Ethernet

```
#include "BS_API.h"

int BS2_RemoveDeviceZone(void* context, BS2_DEVICE_ID deviceId, const
BS2_DEVICE_ZONE_TABLE_ID* Ids, uint32_t IdCount);
```

- [In] *context* : Context
- [In] *deviceId* :
- [In] *Ids* : device zone id
- [In] *IdCount* : device zone id

BS_SDK_SUCCESS , 가

- [BS2_GetDeviceZone](#)
- [BS2_GetAllDeviceZone](#)
- [BS2_SetDeviceZone](#)
- [BS2_RemoveAllDeviceZone](#)
- [BS2_SetDeviceZoneAlarm](#)

From:
<http://kb.supremainc.com/bs2sdk/> - **BioStar 2 Device SDK**

Permanent link:
http://kb.supremainc.com/bs2sdk/doku.php?id=ko:bs2_removedevicezone&rev=1504533621

Last update: **2017/09/04 23:00**