

BS2_SetAntiPassbackZoneAlarm 1
..... 1
..... 1
..... 1
..... 1

[Zone Control API](#) > [BS2_SetAntiPassbackZoneAlarm](#)

BS2_SetAntiPassbackZoneAlarm

```
#include "BS_API.h"

int BS2_SetAntiPassbackZoneAlarm(void* context, uint32_t deviceId, uint8_t
alarmed, BS2_ZONE_ID* zoneIds, uint32_t zoneIdCount);
```

- [In] *context* : Context
- [In] *deviceId* :
- [In] *alarmed* :
- [In] *zoneIds* : anti-passback zone id
- [In] *zoneIdCount* : anti-passback zone id

BS_SDK_SUCCESS , 가

[BS2_GetAntiPassbackZone](#)
[BS2_GetAllAntiPassbackZone](#)
[BS2_GetAntiPassbackZoneStatus](#)
[BS2_GetAllAntiPassbackZoneStatus](#)
[BS2_SetAntiPassbackZone](#)
[BS2_RemoveAntiPassbackZone](#)
[BS2_RemoveAllAntiPassbackZone](#)
[BS2_ClearAntiPassbackZoneStatus](#)
[BS2_ClearAllAntiPassbackZoneStatus](#)

From:

<http://kb.supremainc.com/bs2sdk/> - **BioStar 2 Device SDK**

Permanent link:

http://kb.supremainc.com/bs2sdk./doku.php?id=ko:bs2_setantipassbackzonealarm

Last update: **2016/02/02 14:30**