

BS2_SetLiftLockUnlockZone 1
..... 1
..... 1
..... 1
..... 1

BS2_SetLiftLockUnlockZone

[+ 2.7.0] Lift / .

```
#include "BS_API.h"


int BS2_SetLiftLockUnlockZone(void* context, uint32_t deviceId,
BS2LiftLockUnlockZone* zones, uint32_t zoneCount);
```

[BS2LiftLockUnlockZone](#)

- [In] *context* : Context
- [In] *deviceId* :
- [In] *zones* : Lift lock/unlock zone
- [In] *zoneCount* : Lift lock/unlock zone

BS_SDK_SUCCESS , 가

- [BS2_GetLiftLockUnlockZone](#)
- [BS2_GetAllLiftLockUnlockZone](#)
- [BS2_GetLiftLockUnlockZoneStatus](#)
- [BS2_GetAllLiftLockUnlockZoneStatus](#)
- [BS2_SetLiftLockUnlockZoneAlarm](#)
- [BS2_RemoveLiftLockUnlockZone](#)
- [BS2_RemoveAllLiftLockUnlockZone](#)



From:

<http://kb.supremainc.com/bs2sdk/> - **BioStar 2 Device SDK**

Permanent link:

http://kb.supremainc.com/bs2sdk/doku.php?id=ko:bs2_setliftlockunlockzone

Last update: **2020/08/07 13:03**