

**BS2\_SetLiftLockUnlockZoneAlarm** ..... 1

..... 1

..... 1

..... 1

..... 1

[Zone Control API](#) > [BS2\\_SetLiftLockUnlockZoneAlarm](#)

---

## BS2\_SetLiftLockUnlockZoneAlarm

[+ 2.7.0] Lift

```
#include "BS_API.h"
```

```
int BS2_SetLiftLockUnlockZoneAlarm(void* context, uint32_t deviceId, uint8_t  
alarmed, uint32_t* zoneIds, uint32_t zoneIdCount);
```

- [In] *context* : Context
- [In] *deviceId* :
- [In] *alarmed* :
- [In] *zoneIds* : Lift lock/unlock zone id
- [In] *zoneIdCount* : Lift lock/unlock zone id

BS\_SDK\_SUCCESS , 가

[BS2\\_GetLiftLockUnlockZone](#)  
[BS2\\_GetAllLiftLockUnlockZone](#)  
[BS2\\_GetLiftLockUnlockZoneStatus](#)  
[BS2\\_GetAllLiftLockUnlockZoneStatus](#)  
[BS2\\_SetLiftLockUnlockZone](#)  
[BS2\\_RemoveLiftLockUnlockZone](#)  
[BS2\\_RemoveAllLiftLockUnlockZone](#)

From:  
<http://kb.supremainc.com/bs2sdk/> - **BioStar 2 Device SDK**

Permanent link:  
[http://kb.supremainc.com/bs2sdk./doku.php?id=ko:bs2\\_setliftlockunlockzonealarm](http://kb.supremainc.com/bs2sdk./doku.php?id=ko:bs2_setliftlockunlockzonealarm)

Last update: **2020/07/21 21:08**

