

Table of Contents

BS2_DeActivateFloor	1
Declaration	1
Parameter	1
Return Value	1
See Also	1

[Lift Control API](#) > [BS2_DeActivateFloor](#)

BS2_DeActivateFloor

Configures the priority of when the door gets deactivated. The deactivate priority must be higher than the activate to deactivate the lift.

Declaration

```
#include "BS_API.h"

int BS2_DeActivateFloor(void* context, uint32_t deviceId, BS2_FLOOR_FLAG
flag, BS2_LIFT_ID liftID, uint16_t* floorIndexs, uint8_t floorIndexCount);
```

Parameter

- [In] *context* : Context
- [In] *deviceId* : Device ID
- [In] *flag* : Priority of the deactivate status to add
- [In] *liftID* : Lift ID
- [In] *floorIndexs* : List of floor indexes
- [In] *floorIndexCount* : Number of floor indexes

Return Value

If successfully done, BS_SDK_SUCCESS will be returned.

If there is an error, the corresponding error code will be returned.

See Also

[BS2_GetLift](#)
[BS2_GetAllLift](#)
[BS2_GetLiftStatus](#)
[BS2_GetAllLiftStatus](#)
[BS2_SetLift](#)
[BS2_SetLiftAlarm](#)
[BS2_RemoveLift](#)
[BS2_RemoveAllLift](#)
[BS2_ReleaseFloor](#)
[BS2_ActivateFloor](#)

From:

<http://kb.supremainc.com/bs2sdk/> - **BioStar 2 Device SDK**

Permanent link:

http://kb.supremainc.com/bs2sdk/doku.php?id=en:bs2_deactivatefloor

Last update: **2017/06/28 10:51**