

Table of Contents

BS2_GetAllAntiPassbackZone	1
Declaration	1
Parameter	1
Return Value	1
See Also	1

[Zone Control API](#) > [BS2_GetAllAntiPassbackZone](#)

BS2_GetAllAntiPassbackZone

Retrieves all Anti Passback zones.

Declaration

```
#include "BS_API.h"

int BS2_GetAllAntiPassbackZone(void* context, uint32_t deviceId,
BS2AntiPassbackZone** zoneObj, uint32_t* numZone);
```

[See BS2AntiPassbackZone Structure](#)

Parameter

- [In] *context* : Context
- [In] *deviceId* : Device ID
- [Out] *zoneObj* : Anti Passback zone list pointer
- [Out] *numZone* : Number of Anti Passback zones

NOTE

The *zoneObj* variable needs to return the memory to the system by the [BS2_ReleaseObject](#) function after being used.

Return Value

If successfully done, `BS_SDK_SUCCESS` will be returned.
If there is an error, the corresponding error code will be returned.

See Also

[BS2_GetAntiPassbackZone](#)
[BS2_SetAntiPassbackZone](#)
[BS2_RemoveAntiPassbackZone](#)

BS2_RemoveAllAntiPassbackZone

From:

<https://kb.supremainc.com/kbtest/> - **BioStar Device SDK**

Permanent link:

https://kb.supremainc.com/kbtest/doku.php?id=en:bs2_getallantipassbackzone

Last update: **2016/07/12 09:48**