

Table of Contents

BS2_GetInterlockZone	1
Declaration	1
Parameter	1
Return Value	1
See Also	1

[Zone Control API](#) > [BS2_GetInterlockZone](#)

BS2_GetInterlockZone

[+ V2.6.0] Gets selected Interlock zones.

Declaration

```
#include "BS_API.h"

int BS2_GetInterlockZone(void* context, BS2_DEVICE_ID deviceId,
BS2InterlockZoneBlob* zoneBlob, uint32_t* numZone);
```

[See BS2InterlockZoneBlob Structure](#)

Parameter

- [In] *context* : Context
- [In] *deviceId* : Device ID
- [Out] *zoneBlob* : Interlock zone list pointer
- [Out] *numZone* : Number of Interlock zones

NOTE

The *zoneObj* variable needs to return the memory to the system by the [BS2_ReleaseObject](#) function after being used.

Return Value

If successfully done, `BS_SDK_SUCCESS` will be returned.
If there is an error, the corresponding error code will be returned.

See Also

[BS2_GetInterlockZoneStatus](#)
[BS2_GetAllInterlockZoneStatus](#)
[BS2_SetInterlockZone](#)
[BS2_SetInterlockZoneAlarm](#)

[BS2_RemoveInterlockZone](#)
[BS2_RemoveAllInterlockZone](#)

From:
<https://kb.supremainc.com/kbtest/> - **BioStar Device SDK**

Permanent link:
https://kb.supremainc.com/kbtest/doku.php?id=en:bs2_getinterlockzone

Last update: **2018/03/15 14:34**