

Table of Contents

<i>BS2_GetUserDatabaseInfoFromDir</i>	1
Declaration	1
Parameter	1
Return Value	1
See Also	1

User Management API > [BS2_GetUserDatabaseInfoFromDir](#)

BS2_GetUserDatabaseInfoFromDir

Gets all user data(Number of users, cards, fingerprints, faces) from storage path in device.

Declaration

```
#include "BS_API.h"

int BS2_GetUserDatabaseInfoFromDir(void* context, const char* szDir,
uint32_t* numUsers, uint32_t* numCards, uint32_t* numFingers, uint32_t*
numFaces, IsAcceptableUserID ptrIsAcceptableUserID);
```

Parameter

- [In] *context* : Context
- [Out] *szDir* : Storage path in device
- [Out] *numUsers* : Number of total users
- [Out] *numCards* : Number of total cards
- [Out] *numFingers* : Number of total fingerprints
- [Out] *numFaces* : Number of total faces
- [In] *ptrIsAcceptableUserID* : TBD

NOTE

The zoneObj variable needs to return the memory to the system by the [BS2_ReleaseObject](#) function after being used.

Return Value

If successfully done, BS_SDK_SUCCESS will be returned.

If there is an error, the corresponding error code will be returned.

See Also

[BS2_GetUserListFromDir](#)

[BS2_GetUserInfosFromDir](#)

[BS2_GetUserDatasFromDir](#)

[BS2_GetUserInfosExFromDir](#)

[BS2_GetUserDatasExFromDir](#)

From:

<https://kb.supremainc.com/kbtest/> - **BioStar Device SDK**

Permanent link:

https://kb.supremainc.com/kbtest/doku.php?id=en:bs2_getuserdatabaseinfofromdir

Last update: **2017/09/29 12:39**