

Table of Contents

BS2_SetLift	1
Declaration	1
Parameter	1
Return Value	1
See Also	1

[Lift Control API](#) > [BS2_SetLift](#)

BS2_SetLift

Configures a lift.

Declaration

```
#include "BS_API.h"

int BS2_SetLift(void* context, uint32_t deviceId, BS2Lift* lifts, uint32_t liftCount);
```

[See BS2Lift Structure](#)

Parameter

- [In] *context* : Context
- [In] *deviceId* : Device ID
- [In] *lifts* : List of lifts to be stored
- [In] *liftCount* : Number of lifts

Return Value

If successfully done, BS_SDK_SUCCESS will be returned.
If there is an error, the corresponding error code will be returned.

See Also

[BS2_GetLift](#)
[BS2_GetAllLift](#)
[BS2_GetLiftStatus](#)
[BS2_GetAllLiftStatus](#)
[BS2_SetLiftAlarm](#)
[BS2_RemoveLift](#)
[BS2_RemoveAllLift](#)
[BS2_ReleaseFloor](#)
[BS2_ActivateFloor](#)
[BS2_DeActivateFloor](#)

From:

<http://kb.supremainc.com/bs2sdk/> - **BioStar 2 Device SDK**

Permanent link:

http://kb.supremainc.com/bs2sdk/doku.php?id=en:bs2_setlift

Last update: **2017/06/28 10:49**