

BS2_GetAllFireAlarmZone 1
..... 1
..... 1
..... 1
..... 1

BS2_GetAllFireAlarmZone

가 .

```
#include "BS_API.h"

int BS2_GetAllFireAlarmZone(void* context, uint32_t deviceId,
BS2FireAlarmZone** zoneObj, uint32_t* numZone);
```

BS2FireAlarmZone

- [In] *context* : Context
- [In] *deviceId* :
- [Out] *zoneObj* : fire alarm zone
- [Out] *numZone* : fire alarm zone

zoneObj	BS2_ReleaseObject
---------	-------------------

BS_SDK_SUCCESS , 가

- [BS2_GetFireAlarmZone](#)
- [BS2_GetFireAlarmZoneStatus](#)
- [BS2_GetAllFireAlarmZoneStatus](#)
- [BS2_SetFireAlarmZone](#)
- [BS2_SetFireAlarmZoneAlarm](#)

[BS2_RemoveFireAlarmZone](#)
[BS2_RemoveAllFireAlarmZone](#)

From:
<https://kb.supremainc.com/kbtest/> - **BioStar Device SDK**

Permanent link:
https://kb.supremainc.com/kbtest/doku.php?id=ko:bs2_getallfirealarmzone

Last update: **2016/07/12 10:24**