

BS2_GetDoorStatus 1
..... 1
..... 1
..... 1
..... 1

BS2_GetDoorStatus


가 .

```
#include "BS_API.h"

int BS2_GetDoorStatus(void* context, uint32_t deviceId, uint32_t* doorIds,
uint32_t doorIdCount, BS2DoorStatus** doorStatusObj, uint32_t*
numDoorStatus);
```

BS2DoorStatus

- [In] *context* : Context
- [In] *deviceId* :
- [In] *doorIds* : 가 door id
- [In] *doorIdCount* : door id
- [Out] *doorStatusObj* : door status
- [Out] *numDoorStatus* : door status



BS_SDK_SUCCESS , 가

BS2_GetDoor
BS2_GetAllDoor

BS2_GetAllDoorStatus
BS2_SetDoor
BS2_SetDoor
BS2_SetDoorAlarm
BS2_RemoveDoor
BS2_RemoveAllDoor
BS2_ReleaseDoor
BS2_LockDoor
BS2_UnlockDoor

From:

<http://kb.supremainc.com/bs2sdk/> - **BioStar 2 Device SDK**

Permanent link:

http://kb.supremainc.com/bs2sdk./doku.php?id=ko:bs2_getdoorstatus

Last update: **2016/08/08 15:12**